



Australian Government

Assessment Requirements for MSFFL3119

Install timber battens and plywood in preparation to install strip timber

Release: 1

Assessment Requirements for MSFFL3119 Install timber battens and plywood in preparation to install strip timber

Modification History

Release 1. Supersedes and is equivalent to MSFFL3085 Install battens or plywood in preparation for strip timber. Changes to title, application, elements and performance criteria to improve clarity and consistency across MSFFL units. Changes to assessment requirements.

Performance Evidence

There must be evidence the candidate has completed the tasks in the elements and performance criteria of this unit of competency and has demonstrated the ability to install according to job instructions:

- full-thickness battens packed to achieve a level surface in one complete area
- full battens scribed down to thinner sizes to fully support the subfloor
- plywood mechanically fixed to a concrete subfloor.

Knowledge Evidence

There must be evidence the candidate has knowledge of:

- manufacturer installation instructions for:
 - moisture vapour barrier
 - timber battens with a density greater than 600 Kg/m³
- manufacturer use instructions for adhesives including:
 - elastomeric
 - polyurethane
 - polyvinyl alcohol (PVA)
- the safe and correct use of, and maintenance requirements for tools and equipment for, installing moisture vapour barrier, timber battens and plywood
- the most common issues that can arise when installing moisture vapour barrier, timber battens and plywood and how to avoid and respond to them
- workplace policies and procedures relevant to their job role and responsibilities including for:
 - installing moisture vapour barrier, timber battens and plywood
 - communication and reporting
 - environmental protection and sustainability, including maximising resource utilisation and minimising waste
 - quality indicators for completed work and process improvements
 - work health and safety, including the use of personal protective equipment and safety data sheets
 - work planning

- how to identify if a subfloor is suitable for installing a moisture vapour barrier, timber battens and plywood
- how to identify if a moisture vapour barrier, timber battens and plywood are installed correctly.

Assessment Conditions

Skills must have been demonstrated in the workplace or in a simulated environment that reflects workplace conditions and contingencies. The following conditions must be met for this unit:

- use of suitable facilities, equipment and resources, including:
 - locations in which to install a moisture vapour barrier, timber battens and plywood before installing strip timber
 - moisture vapour barrier, timber battens, plywood and other materials required by job instructions
 - equipment and tools required for the activities set out in the elements and performance criteria, including those to control hazards
 - job instructions and workplace procedures.

Assessors must satisfy the NVR/AQTF mandatory competency requirements for assessors.

Links

Companion Volume implementation guides are found in VETNet – -

<https://vetnet.gov.au/Pages/TrainingDocs.aspx?q=0601ab95-583a-4e93-b2d4-cfb27b03ed73>