

Australian Government

# TLID2016 Load and unload explosives/dangerous goods

Release: 1

### TLID2016 Load and unload explosives/dangerous goods

#### **Modification History**

Release 1. This is the first release of this unit of competency in the TLI Transport and Logistics Training Package.

# Application

This unit involves the skills and knowledge required to load and unload explosives/dangerous goods in a range of operational situations, in accordance with relevant Australian and state/territory regulations including current Australian Dangerous Goods (ADG) Code, current Australian Code for the Transport of Explosives by Road and Rail (AE Code), and mass and loading regulations.

It includes identifying explosives/dangerous goods, loading and unloading explosives/dangerous goods using appropriate equipment, securing and protecting vehicle load, and checking vehicle to ensure load is secure and vehicle is marked in accordance with regulatory requirements.

Work is performed under limited or minimum supervision.

No licensing, legislative or certification requirements apply to this unit at the time of publication.

#### **Pre-requisite Unit**

Not applicable.

## **Competency Field**

D – Load Handling

#### **Unit Sector**

Not applicable.

### **Elements and Performance Criteria**

ELEMENTS	PERFORMANCE CRITERIA
Elements describe the essential outcomes.	Performance criteria describe the performance needed to demonstrate achievement of the element.
1 Prepare to load and unload vehicle	1.1 Explosives/dangerous goods are identified and their characteristics are taken into account in accordance with relevant emergency procedures when determining

appropriate handling, loading and storage procedures

- 1.2 Job hazards are identified and required action is taken to minimise, control or eliminate identified hazards
- 1.3 Compatibility of explosives/dangerous goods is taken into account when assembling and segregating cargo for loading
- 1.4 Vehicle/loading equipment is checked to ensure it is suitable to handle/carry load

#### 2 Load/unload vehicle 2.1 Vehicle is loaded/unloaded in accordance with workplace procedures and current ADG/AE Code as required

- 2.2 Load is segregated according to class and subsidiary risk, and load distribution is checked in accordance with workplace procedures, relevant mass and loading regulations, and current ADG/AE Code as required
- 2.3 Personal protective equipment is used during loading/unloading operations as required for type of explosives/dangerous goods concerned
- 2.4 Emergency procedures are followed in an incident or accident when loading or unloading explosives and/or dangerous goods
- 3 Secure and protect 3.1 Vehicle load is secured using correct load restraint and vehicle load protection equipment for different loads, vehicles and carriage conditions concerned
  - 3.2 Load is protected in accordance with legal and workplace safety requirements
  - 3.3 Load distribution is checked to ensure it is even, legal and within safe working capacity of vehicle
  - 3.4 Vehicle is clearly marked/placarded to indicate carriage of explosives and/or dangerous goods, in accordance with government regulations and workplace procedures
- Check vehicle 4.1 Loaded vehicle is inspected and checked to ensure it is 4 suitable to carry explosives/dangerous goods, and load weight and dimensions are within vehicle safe carrying capacity and equipment capability
  - 4.2 Loaded vehicle is checked to ensure it can be safely parked and secured
  - 4.3 Dangerous goods declaration and required transportation

documentation for cargo is completed in accordance with workplace requirements

# **Foundation Skills**

Foundation skills essential to performance are explicit in the performance criteria of this unit of competency.

# **Range of Conditions**

Range is restricted to essential operating conditions and any other variables essential to the work environment.

Non-essential conditions can be found in the Companion Volume Implementation Guide.

# **Unit Mapping Information**

This unit replaces and is equivalent to TLID2016A Load and unload explosives and dangerous goods.

# Links

Companion Volume implementation guides are found in VETNet https://vetnet.gov.au/Pages/TrainingDocs.aspx?q=df441c6e-213d-43e3-874c-0b3f7036d851