



Australian Government

TLID3040 Control lift and movement of crane

Release: 1

TLID3040 Control lift and movement of crane

Modification History

Release 1. This is the first release of this unit of competency in the TLI Transport and Logistics Training Package.

Application

This unit involves the skills and knowledge required to control the lift and movement of a crane when the load is out of the crane operator's view, in accordance with workplace principles, procedures and regulations.

It includes providing lift instructions to the crane operator using appropriate communication methods, monitoring the lift and placing and securing a load.

Work must be carried out in compliance with the relevant state/territory authority licence/permit requirements and regulations for operating mobile cranes up to and including 20 tonnes.

Work is performed with limited or minimum supervision, and with limited accountability and responsibility for self and others in achieving prescribed outcomes.

No licensing, legislative or certification requirements apply to this unit at the time of publication.

Pre-requisite Unit

Not applicable.

Competency Field

D – Load Handling

Unit Sector

Not applicable.

Elements and Performance Criteria

ELEMENTS

PERFORMANCE CRITERIA

Elements describe the essential outcomes.

Performance criteria describe the performance needed to demonstrate achievement of the element.

1 Provide lift instructions

- 1.1 Load movement is performed in accordance with planned hazard prevention and control measures in line with appropriate Australian standards, codes of practice, guidelines and

manufacturer specifications

- 1.2 Agreed communication and signal methods are used to safely coordinate load movement
- 1.3 Clear, precise and concise verbal communication and signals are used
- 1.4 All relevant parameters are taken into account in instructions to ensure a safe, stable and smooth lift

2 Monitor lift

- 2.1 Load is constantly monitored to ensure it remains stable
- 2.2 Load conditions that may affect continuing stability are identified and monitored
- 2.3 Temporary bracing and/or load support is maintained until continuing stability is ensured
- 2.4 Unplanned situations are responded to in accordance with workplace procedures in a manner that minimises risk to personnel and equipment
- 2.5 Site emergency procedures are followed

3 Place and secure load

- 3.1 Appropriate materials for fixing and anchoring the load are checked and selected in line with manufacturer specifications
- 3.2 Appropriate fixing methods are used to secure load in line with manufacturer specifications and guidelines
- 3.3 Temporary securing is installed where hazards and weather conditions may vary during the load movement

Foundation Skills

Foundation skills essential to performance are explicit in the performance criteria of this unit of competency.

Range of Conditions

Range is restricted to essential operating conditions and any other variables essential to the work environment.

Non-essential conditions can be found in the Companion Volume Implementation Guide.

Unit Mapping Information

This unit replaces and is equivalent to TLID3040A Control lift and movement of crane.

Links

Companion Volume implementation guides are found in VETNet -

<https://vetnet.education.gov.au/Pages/TrainingDocs.aspx?q=df441c6e-213d-43e3-874c-0b3f7036d851>