



Australian Government

TLILIC0022 Licence to operate a slewing mobile crane (up to 20 tonnes)

Release: 1

TLILIC0022 Licence to operate a slewing mobile crane (up to 20 tonnes)

Modification History

Release 1. This is the first release of this unit of competency in the TLI Transport and Logistics Training Package.

Application

This unit specifies the skills and knowledge required to safely operate a slewing mobile crane with a Maximum Rated Capacity (MRC) up to 20 tonnes in accordance with all relevant legislative responsibilities. Competence in this unit, does not in itself result in a High-Risk Work Licence (HRWL) to operate this plant.

Slewing mobile crane means a mobile crane incorporating a boom or jib that can be slewed, but does not include:

- a front-end loader, or
- a backhoe, or
- an excavator, or
- other earth moving equipment, when configured for crane operation.

A person performing this work is required to hold a slewing mobile crane with a MRC up to 20 tonnes HRWL.

This unit requires a person operating a slewing mobile crane with an MRC up to 20 tonnes to:

- plan for the work/task
- prepare for the work/task
- perform work/task
- pack up.

Licensing/Regulatory Information

Legislative and regulatory requirements are applicable to this unit of competency.

This unit is based on the licensing requirements of Part 4.5 of the Model Work Health and Safety (WHS) regulations and meets Commonwealth, state and territory HRWL requirements.

The National Assessment Instrument (NAI) is the mandated assessment for the HRWL to operate the relevant licensing class as detailed in this unit.

Pre-requisite Unit

Not applicable.

Competency Field

LIC - Licencing Units.

Unit Sector

Not applicable.

Elements and Performance Criteria

ELEMENTS

Elements describe the essential outcomes.

1 Plan work/task

PERFORMANCE CRITERIA

Performance criteria describe the performance needed to demonstrate achievement of the element.

- 1.1** Task requirements are identified from work orders or equivalent, a lift plan is confirmed with associated personnel and a site inspection is conducted in accordance with workplace procedures
- 1.2** Work area operating surface is confirmed to determine ground suitability for operational use of mobile crane in accordance with workplace procedures
- 1.3** Mobile crane Rated Capacity (RC) and the lifting gear Working Load Limit (WLL) are established for the load/s and work/task requirements in accordance with manufacturer requirements and workplace procedures
- 1.4** Appropriate paths for operating the mobile crane and moving and placing load/s in work area are assessed and determined in accordance with workplace procedures
- 1.5** Relevant hazard identification and risk elimination/control measures are applied and advised to associated personnel in accordance with workplace procedures
- 1.6** Traffic management plan implementation is confirmed in accordance with workplace procedures
- 1.7** Appropriate communication procedures are identified with associated personnel in accordance with workplace procedures
- 1.8** All crane and lifting operations are confirmed to ensure relevant work area requirements are correct in

accordance with a lift plan and workplace procedures

- 1.9** Information required to ensure that lifting equipment and gear inspection, use, maintenance and storage complies with manufacturer requirements is obtained and interpreted

2 Prepare for work/task

- 2.1** Consultation with workplace personnel is established and maintained to ensure lift plan is clear and consistent with site requirements in accordance with a lift plan and workplace procedures
- 2.2** Risk control measures for hazards identified are checked for implementation in accordance with the lift plan and safe work procedures
- 2.3** Mobile crane is accessed safely in accordance with manufacturer requirements and safe work procedures
- 2.4** Pre-start mobile crane checks are carried out and any damage and defects are reported, recorded and appropriate action is taken in accordance with manufacturer requirements and safe work procedures
- 2.5** Mobile crane is set up correctly with any lifting gear and stabilised as per the lift plan in accordance with relevant manufacturer requirements, including load chart/s and safe work procedures
- 2.6** Fly jib is set up as required in accordance with specific manufacturer requirements and safe work procedures
- 2.7** Operational checks are carried out and any damage and defects are reported, recorded and appropriate action is taken in accordance with manufacturer requirements and safe work procedures
- 2.8** Crane logbook is checked to confirm current compliance, is correct for the crane type, is completed and signed and required rectifications have been signed off in accordance with manufacturer requirements and safe work procedures
- 2.9** Weather and work environment conditions are assessed to determine any impact on mobile crane operations in accordance with manufacturer requirements and safe work procedures

2.10 Weight of the load is confirmed

2.11 Derated WLL of lifting equipment resulting from selected slinging techniques is calculated and confirmed as suitable to meet the requirements of the lift plan

2.12 Suitable lifting points and slinging techniques are identified

2.13 Lifting equipment and gear are confirmed as ready for safe use

2.14 Load destination stability is confirmed ensuring it is able to bear the load and is prepared for safe access and landing

3 Perform work/task

3.1 Lifts are determined within the RC of the mobile crane in accordance with the load chart/s and lift plan

3.2 Boom/jib and hook block are safely positioned over the load following directions from associated personnel in accordance with the lift plan and safe work procedures

3.3 Main hook, including any lifting gear where required, are connected to the load and used safely in accordance with the lift plan, safe work procedures and manufacturer requirements

3.4 Test lift is carried out in accordance with dogging and safe work procedures

3.5 Loads are transferred using relevant crane movements and tag lines, as required, in accordance with lift plan and safe work procedures

3.6 Load and crane movement is monitored constantly and crane is operated safely in accordance with lift plan and safe work procedures

3.7 All required communication signals are correctly interpreted and followed whilst crane is operated in accordance with the lift plan and safe work procedures

3.8 Load is lowered and landed safely in accordance with lift plan and safe work procedures

- 3.9** Lifting gear is positioned for safe disconnection from the load and crane is positioned for next task in accordance with lift plan and safe work procedures
 - 3.10** Lifting equipment and gear are inspected for defects, and defective items are isolated, tagged and reported
- 4 Pack up**
 - 4.1** Crane boom/jib, lifting gear and associated equipment are stowed and secured as required in accordance with manufacturer requirements and safe work procedures
 - 4.2** Crane fly jib is removed to storage position and secured as required in accordance with manufacturer requirements and safe work procedures
 - 4.3** Relevant motion locks and brakes are applied as required in accordance with manufacturer requirements and safe work procedures
 - 4.4** Outriggers, plates and/or packing are stowed and secured in accordance with manufacturer requirements and safe work procedures
 - 4.5** Crane is shut down and secured to prevent unauthorised access/use in accordance with safe work procedures
 - 4.6** Shutdown crane checks are carried out in accordance with safe work procedures and manufacturer requirements

Foundation Skills

Foundation skills essential to performance are explicit in the performance criteria of this unit of competency.

Range of Conditions

Range is restricted to essential operating conditions and any other variables essential to the work environment.

Non-essential conditions may be found in the TLI Transport and Logistics Training Package Companion Volume Implementation Guide.

Unit Mapping Information

This unit replaces and is equivalent to TLILIC0010 Licence to operate a slewing mobile crane

(up to 20 tonnes).

Links

Companion Volume Implementation Guides are found in VETNet -

<https://vetnet.gov.au/Pages/TrainingDocs.aspx?q=df441c6e-213d-43e3-874c-0b3f7036d851>