



Australian Government

UETDRIS015 Install low voltage mobile generator

Release: 1

UETDRIS015 Install low voltage mobile generator

Modification History

Release 1. This is the first release of this unit of competency in the UET Transmission, Distribution and Rail Sector Training Package Release 2.0.

Application

This unit involves the skills and knowledge required to install a low voltage (LV) mobile generator in the electricity supply industry (ESI).

It includes selecting, connecting, synchronising, operating and disconnecting of a temporary mobile generator to LV network assets to maintain supply.

The application of the skills and knowledge described in this unit may require a licence/registration to practice in the workplace.

Other conditions may also apply under state and territory legislative and regulatory licensing requirements which must be confirmed prior to commencing this unit.

Pre-requisite Unit

UEECD0007 Apply work health and safety regulations, codes and practices in the workplace

UEECD0044 Solve problems in multiple path circuits

UEECD0046 Solve problems in single path circuits

UEECD0051 Use drawings, diagrams, schedules, standards, codes and specifications

UEEEL0020 Solve problems in low voltage a.c. circuits

UEEEL0021 Solve problems in magnetic and electromagnetic devices

UETDREL001 Apply environmental requirements

UETDREL005 Work safely in the vicinity of live electrical apparatus

Competency Field

Industry Specific Cross Discipline

Unit Sector

Not applicable.

Elements and Performance Criteria

ELEMENTS

PERFORMANCE CRITERIA

Elements describe the essential outcomes.

Performance criteria describe the performance needed to demonstrate achievement of the element.

1 Prepare to install LV mobile generator

- 1.1 Legislation, regulations, standards, codes of practice and organisational workplace requirements for the work to be performed are referred to and confirmed
- 1.2 Work plan is obtained and confirmed in accordance with workplace requirements
- 1.3 Materials required for work are determined and obtained in accordance with work plan and workplace requirements
- 1.4 Plant, tools, equipment and personal protective equipment (PPE) required for work are determined, obtained and confirmed in working order
- 1.5 Hazards are identified, risks assessed and control measures identified and applied
- 1.6 Work is prioritised and sequenced for completion in accordance with work plan and workplace requirements
- 1.7 Worksite is prepared in accordance with the work plan and workplace requirements
- 1.8 Traffic management plan is confirmed as being in place in accordance with workplace requirements

2 Carry out the installation of LV mobile generator

- 2.1 Legislation, regulations, standards, codes of practice and organisational workplace requirements for the work to be performed are applied and monitored
- 2.2 Lifting, climbing, working at heights and the use of plant, tools, equipment and PPE are carried out in accordance with workplace requirements
- 2.3 Hazard control measures are monitored in accordance with workplace requirements
- 2.4 LV mobile generator is installed in accordance with the work plan and workplace requirements
- 2.5 LV mobile generator is synchronised to LV network in accordance with the work plan and workplace

requirements

- 3 Complete work and documentation**
- 2.6 LV mobile generator is monitored in accordance with the work plan and workplace requirements
 - 3.1 Completed work is checked for compliance against the work plan and workplace requirements
 - 3.2 Worksite is rehabilitated, cleaned and made safe in accordance with workplace requirements
 - 3.3 Plant, tools and equipment are cleaned, checked and returned to storage in accordance with workplace requirements
 - 3.4 Surplus materials are returned to storage or disposed of in accordance with workplace requirements
 - 3.5 Work records, reports and documentation are completed in accordance with workplace requirements

Foundation Skills

Foundation skills essential to performance are explicit in the performance criteria of this unit of competency.

Range of Conditions

Range is restricted to essential operating conditions and any other variables essential to the work environment.

Non-essential conditions may be found in the UET Transmission, Distribution and Rail Sector Training Package Companion Volume Implementation Guide.

Unit Mapping Information

This unit replaces and is equivalent to UETTDRIS61 Install mobile generation set for synchronised LV Genset.

Links

Companion Volume Implementation Guides are found in VETNet - <https://vetnet.gov.au/Pages/TrainingDocs.aspx?q=229bace1-b7bc-4653-9300-dffb13ecfad7>